

315SS (15" & 18") Front Panel Kit Installation Instructions

<u>CONTAINS:</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>QTY</u>	<u>DESCRIPTION</u>
	1	Door Panel Assy (size will vary)	1	Kit, Carbon Finish Care (not included in all Kits)
	1	Bracket, Panel SS	16	Screws, #8-32x1/2 Truss HD
	1	Bracket, Upr Drawer	2	Washer, Star 3/16"
	2	Bolt, #10-24x1-1/2 Rd Hd	1	Instructions

PROCEDURE: (Refer to the illustration below)

1. Remove handle-side bracket from face of door.
2. Secure handle-side bracket to door panel assembly using eight screws, provided.
3. Remove bottom door bracket from door and replace with bottom door bracket provided. Then, secure with four screws.
4. Engage four tabs of handle-side bracket into pockets in the face of door.
5. Secure panel to door with two screws at upper door bracket, four screws at bottom door bracket.
6. Check for proper alignment and make adjustments if necessary.

