



SABBATH

The Sabbath feature remains on even after a power outage.

To turn the Sabbath feature on or off:

- 1 To turn on, touch and hold Quick for approximately 10 seconds until "Sabbath" appears on the display. "Sabbath" appears on the display until the Sabbath feature is turned off.
- 2 To turn off, touch and hold Quick for approximately 10 seconds until "Sabbath Off" appears on the display.

IMPORTANT NOTE: Child lock and Sabbath feature cannot be turned on at the same time.

