


Contents

CRISPER	
1	Cover, crisper
1	Instructions

Crisper Cover Installation

- 1 To install, pull the upper drawer all the way out, place the back edge of the crisper cover onto the top of the drawer.
Refer to the illustration below.



Crisper cover.

