

1 Water Filtration System

2 Air Purification System

3 Adjustable Shelves

4 Refrigerator Storage

5 Door Shelves

6 Condenser

Touch Control Panel

Temperature can be adjusted in one-degree increments on the home screen. The temperature is preset at 38°F (3°C).

To adjust temperature, touch the temperature. Touch + or – until the desired temperature is displayed.

To adjust additional settings, touch  on the control panel.



Home Screen

Settings



Adjust refrigerator drawer temperature and humidity



Turn ice maker and max ice on or off



Turn air purifier on or off



Adjust soft on lighting and accent lighting (if applicable)



Turn night mode on or off



Turn the dispenser on or off (if applicable)



Turn door alarm on or off and adjust duration



Adjust door alarm volume and tone



Turn water filter reminder on or off



Turn connect on or off



Turn the unit on or off



Turn Sabbath on or off



Adjust temperature units



Select language




System information



View troubleshooting and service information


1 Water Filtration System

'Change Water Filter' appears on the control panel when the cartridge needs to be replaced. Touch 'Snooze' to delay reminder for 24 hours or until filter can be replaced. Replacement filters can be ordered online at subzero.com/store. Once replaced, follow instructions on the control panel.




2 Air Purification System

'Change Air Filter' appears on the control panel when the cartridge needs to be replaced. Touch 'Snooze' to delay reminder for 24 hours or until filter can be replaced. Replacement filters can be ordered online at subzero.com/store. Once replaced, follow instructions on the control panel.




3 Adjustable Shelves

To remove a shelf, tilt the shelf up, then lift up and out. To install, insert the shelf in the tracks along the back wall, then lower the front until it locks into position.




4 Refrigerator Storage Drawers

To remove, pull the drawer open until it stops. Pull the two tabs (bottom corners of the drawer) forward, then lift up and out. To install, push the drawer slides in. Align the drawer with the slides and push back. Press down on the drawer front to engage slides.




5 Door Shelves

To remove a door shelf or the dairy compartment, lift from the bottom and slide out. To install, place in the desired position and slide the shelf down onto the guides.



6 Condenser

Clean the condenser every 6–12 months using a soft-bristle brush. To clean, turn power off at the control panel, rotate the bottom edge of the grille upward, and vacuum the condenser in the direction of the fins (up and down).



For service and support, call 800-222-7820, or visit subzero.com.



9051733 REV-A