



1 Water Filtration System

2 Air Purification System

3 Adjustable Shelves

4 Refrigerator Storage

5 Freezer Storage

6 Ice Bin7 Door Shelves

8 Condenser

Touch Control Panel

Temperatures can be adjusted in one-degree increments on the home screen. Combination units have separate temperature controls for refrigerator and freezer. Temperatures are preset at 38°F (3°C) and 0°F (-18°C).

To adjust temperature, touch the temperature to be adjusted. Touch + or – until the desired temperature is displayed.

To adjust additional settings, touch 👸 on the control panel.



Home Screen

Settings

Adjust refrigerator drawer temperature and humidity Turn ice maker and max ice on or off # Turn air purifier on or off -\\. Adjust soft on lighting and accent lighting (if applicable) 6 Turn night mode on or off |•| Turn the dispenser on or off (if applicable) \Box Turn door alarm on or off and adjust duration))) Adjust door alarm volume and tone Turn water filter reminder on or off 1 Turn connect on or off

Turn the unit on or off

Turn Sabbath on or off

Solve Adjust temperature units


Select language

System information

View troubleshooting and service information


1 Water Filtration System

'Change Water Filter' appears on the control panel when the cartridge needs to be replaced. Touch 'Snooze' to delay reminder for 24 hours or until filter can be replaced. Replacement filters can be ordered online at subzero. com/store. Once replaced, follow instructions on the control panel.



2 Air Purification System

'Change Air Filter' appears on the control panel when the cartridge needs to be replaced. Touch 'Snooze' to delay reminder for 24 hours or until filter can be replaced. Replacement filters can be ordered online at subzero. com/store. Once replaced, follow instructions on the control panel.



3 Adjustable Shelves

To remove a shelf, tilt the shelf up, then lift up and out. To install, insert the shelf in the tracks along the back wall, then lower the front until it locks into position.



4 Refrigerator Storage Drawer

To remove, pull the drawer open until it stops. Pull the two tabs (bottom corners of the drawer) forward, then lift up and out. To install, push the drawer slides in. Align the drawer with the slides and push back. Press down on the drawer front to engage slides.




5 Freezer Storage Drawers

To remove, pull open until drawer stops. Raise the drawer front and pull out drawer. To install, raise the front of drawer and place onto the slides. Align the back of the drawer with hooks on slide, then align the white pegs at the front of slide with the holes at the front of the drawer.



6 Ice Bin

To remove the ice bin, pull the freezer drawer open until it stops and lift the bin out. To install, place in the drawer with tabs on the bottom of the bin aligned with slots in the drawer.



7 Door Shelves

Door Shelves

To remove a door shelf or the dairy compartment, lift from the bottom and slide out. To install, place in the desired position and slide the shelf down onto the guides.



8 Condenser

Clean the condenser every 6–12 months using a soft-bristle brush. To clean, turn power off at the control panel, rotate the bottom edge of the grille upward, and vacuum the condenser in the direction of the fins (up and down).



For service and support, call 800-222-7820, or visit subzero.com.



9051734 REV-A