



#811184, 811186, 814451, 814453
PRO Series Ventilation Switch Bezel Removal

CONTAINS:

<u>QTY</u>	<u>DESCRIPTION</u>
1	Bezel Assembly
1	Bezel Mounting Bracket
2	6-32 X .250, FL, Screw
1	Instructions

PROCEDURE:

1. To remove the bezel bracket, extract two screws. Then push the bezel bracket towards the front of the hood to disengage plastic clips securing the bracket. Next, rotate downward to remove (See Figure 1).
2. To install the bezel bracket, loosely attach the bracket with two screws and place the bracket side of the bezel into the hood. Next, slide the bracket towards the front of the hood to allow the bezel to sit flush against the hood and then slide towards the rear. Secure the two screws to lock the assembly into place.




Figure 1. Switch Bezel Removal.