

Model 315 - 15"-18" Filler Kit Installation Instructions

PROCEDURE: (Refer to the illustration below)

1. Determine door swing of unit. (The filler panel is positioned on the handle side of unit.)
2. Remove backing paper from pressure sensitive tape.
3. Position filler panel even with top of icemaker and flush with cabinet face.
4. Using the filler panel as a template, drill 1/8" diameter holes for the four mounting screws.

⚠ CAUTION

Do NOT drill more than 1/2" deep into unit.

5. Install four screws.
6. Install appropriate kickplate/grille.

