

CONTENTS

1	Handle
2	Standoff
2	Screw, #10-24 x 2" (tubular handle only)
2	Screw, #10-24 x 2 ¹ / ₄ "
2	Screw, #10-24 x 2 ¹ / ₂ " (pro handle only)
2	Washer, flat
2	Washer, star

HANDLE DIMENSIONS

TUBULAR HANDLE A

60 ³ / ₄ "	55 ⁷ / ₁₆ "
50 ¹ / ₈ "	47 ¹ / ₈ "
43"	36 ⁹ / ₁₆ "
40 ¹ / ₈ "	34 ¹³ / ₁₆ "
37"	30 ⁹ / ₁₆ "
33 ¹ / ₄ "	30 ¹ / ₄ "
31"	24 ⁹ / ₁₆ "
27 ¹ / ₄ "	24 ¹ / ₄ "
25"	18 ⁹ / ₁₆ "
24 ¹ / ₄ "	21 ¹ / ₄ "
22 ¹ / ₂ "	19 ¹ / ₂ "
21 ¹ / ₄ "	18 ¹ / ₄ "
20 ¹ / ₂ "	17 ¹ / ₂ "

PRO HANDLE A


56 ¹¹ / ₁₆ "	55 ⁷ / ₁₆ "
48 ³ / ₈ "	47 ¹ / ₈ "
42"	40 ³ / ₄ "
36 ¹ / ₁₆ "	34 ¹³ / ₁₆ "
31 ¹ / ₂ "	30 ¹ / ₄ "
30"	28 ³ / ₄ "
25 ¹ / ₂ "	24 ¹ / ₂ "
24"	22 ³ / ₄ "
22 ¹ / ₂ "	21 ¹ / ₄ "
20 ¹ / ₂ "	19 ¹ / ₄ "
19 ¹ / ₂ "	18 ¹ / ₄ "




TUBULAR AND PRO HANDLE INSTALLATION

Panels thicker than $\frac{3}{4}$ " may require additional counter bore depth or longer screws.

- 1 Determine the overall length of the handle.
IMPORTANT NOTE: For pro handles, the overall length includes the standoffs.
- 2 Use the chart to determine the correct hole location, then mark and drill two $\frac{7}{32}$ " holes.



- 3 Counter bore panels so the screw heads and washers are completely recessed.
- 4 Place a star and flat washer on each screw, then insert the screw through the panel.



- 5 Insert the screws through the standoffs and into the handle.
- 6 Tighten the screws to secure the handle to the panel.